

GINGERBREAD TRAMPOLINE

Please check that you have all parts. (Located in attached bag)

- 2 ground stakes
- 2 wing bolt
- 1 pkg. of asst. color clips (replacement)
- 1 silver 1-3 reverse controller

Unfold display being careful not to stretch any attached wires. There are two hinges on the display. One is between the top and middle gingerbread men and one is in the middle of the bottom gingerbread man. Attach two small metal plates at hinges together by screwing wing bolt into metal plates to hold up display. Make sure bolt is on opposite side of the nut which is attached. Do not screw bolt into the side with the nut first.

Attach ground stakes by screwing them into the bottom provided slots. You may need an adjustable wrench.

Gingerbread Trampoline will need extra support which is not included. You can do this with an extra stakes placed behind the display, driven into the ground. Lean display against stake(s) and push ground stakes gently into the ground. You can do this with your foot and using a back and forth motion to inch each side gradually into the ground. Tie to the frame using a twist tie or a cable tie.

1. First plug controller to an extension cord.
2. Each Gingerbread Man is labeled Green 1, Red 2, or Yellow 3. Plug the Green 1 in to the Green 1 on the controller. Plug the Red 2 into the Red 2 on the controller. Plug the Yellow 3 into the Yellow 3 on the controller. (note only gingerbread men plug to controller) Adjust speed to your liking
3. Plug the unmarked plug at bottom of trampoline into an extension cord. This does not plug to the controller.

