


CAROUSEL 3-D

Please check that you have all parts. (Located in attached bag)

- 1 pkg of asst. color clips (replacement)
- 18 wing bolts and nuts
- 25 cable ties
- 12 extension cords (to reach to controller)
- 1 large 3 point controller


1. You will need 2 or 3 people to help for set up.
2. Choose a level spot to place the carousel.
3. Unfold display being careful not to stretch any attached wires. There are 19 pieces to the 3 D Carousel. There are hinges on each piece. Attach the two small metal plates at the hinges together by screwing wing bolt into metal plates to hold up display.
4. Set up center panels first. Hold each one in place in the center and keep adding panels until all 9 panels are up. Then use cable ties to connect at the top, middle and bottom. The display should free stand now. (see illustration)
5. Attach ball at the top of the carousel by inserting post into the metal tube. Drop cords to the bottom center to plug to controller later. Use extension cords provided to get to the bottom.
6. Straighten all clips on panels before attaching Carousel Horse panels.
7. Place Carousel horse panels around the outer perimeter. Starting with 3 blue in a row, 3 pink and 3 orange. Each set of 3 horses is the same. Use the cable ties to attach the horse panel frames at the top and bottom of the center panels. Leave one panel open like a door so you can access the controller and plugs in the center. (see illustration)
8. Straighten clips on horse panels.
9. The bottom of the carousel that is green (green part on horse panel) will plug end to end resulting with only one male plug




There are 9 of these middle panels. Connect all 9 at the center pole with cable ties provided. Fan out the sides as you go.

aerial view of panels


1



2



3



4

